
Fail Safe Vacuum Braking System



Locate away from area which may draw in dust when used and put inline air filter.

NOTES

The PNP Railways vacuum actuator has an integral valve which allows the tank/reservoir charge when the diaphragm is allowed full travel in the realease position.

RIDE ON RAILWAYS LTD